

WARNING

~~Clearing air filter can allow dirt to enter the oil pump and cause damage to the engine.~~
2. IF THE OIL DELIVERY RATE DROPS, the lubricator should be checked for proper operation.
~~Check the oil level in the oil reservoir and the oil filter.~~